



Important tip when installing gas valves into lantern

Invert the bottom washer so the recess is against the bottom of the lantern

That way, when you tighten the brass 90 fitting and it reaches the stopping point, you can use your plyers to force the 90 fitting to the correct position facing the copper tubing. The washer will bend instead of the brass 90 fitting snapping off

Any questions, please call Customer Service at
225-296-6610